

# DuPont™ Vertrel® MCA

Specialty Fluid

## Precision Cleaning

### Introduction

Vertrel® MCA is a proprietary azeotrope of Vertrel® XF hydrofluorocarbon (2,3-dihydrodecafluoropentane) with trans-1,2-dichloroethylene. It is ideally suited for use in vapor degreasing equipment. Its enhanced solvency power, compared to Vertrel® XF alone, makes it particularly effective for precision and specialty cleaning with difficult soils.

Vertrel® MCA has “zero” ozone-depletion potential, and low global warming potential. It can replace CFC-113, methyl chloroform (1,1,1-TCA), hydrochlorofluorocarbons (HCFCs), and perfluorocarbons (PFCs) in many applications. Vertrel® MCA is accepted by the U.S. Environmental Protection Agency (EPA) under the Significant New Alternatives Policy (SNAP) program, as a substitute for ozone-depleting substances.

Physical properties of Vertrel® MCA are shown in **Tables 1 and 2**.

**Table 1**  
Physical Properties

Property <sup>a</sup>	Unit	Vertrel® MCA	CFC-113
Molecular Weight	—	156	187
Boiling Point	°C (°F)	39 (102)	47.6 (117.6)
Liquid Density	g/cc lb/gal	1.41 11.8	1.56 13.1
Vapor Pressure	mm Hg psia	464 9.0	334 6.5
Surface Tension	dyn/cm	15.2	17.3
Freezing Point	°C (°F)	<-50 (<-58)	-35 (-31)
Solubility of Water	wt%	0.065	0.011
Heat of Vaporization at Boiling Point	cal/g Btu/lb	43.3 77.9	35.1 63.1
Heat Capacity	cal/g°C Btu/lb°F	0.27 0.27	0.21 0.21
Viscosity	cPs	0.49	0.68
Flash Point			
Closed Cup <sup>b</sup>	—	None	None
Open Cup <sup>c</sup>	—	None	None
Vapor Flammability in Air			
Lower Limit	vol%	None	None
Upper Limit	vol%	None	None

<sup>a</sup> At 25°C (77°F) except where indicated.

<sup>b</sup> Pensky-Martens Closed Cup Tester (ASTM D 93)

<sup>c</sup> Tag Open Cup Tester (ASTM D 1310)

**Table 2**  
Density and Vapor Pressure Change with Temperature

Temperature, °C (°F)	Density, g/cc (lb/gal)	Vapor Pressure, mmHg (psia)
0 (32)	1.47 (12.3)	162 (3.1)
10 (50)	1.44 (12.0)	258 (5.0)
20 (68)	1.42 (11.8)	375 (7.3)
25 (77)	1.41 (11.8)	464 (9.0)
30 (86)	1.39 (11.6)	552 (10.7)
40 (104)	1.37 (11.4)	795 (15.4)
50 (122)	1.35 (11.3)	1111 (21.5)
60 (140)	1.33 (11.1)	1509 (29.2)

### Cleaning Process

Vapor degreasing should be used for optimum cleaning effectiveness and economy. Modern vapor containment technology is recommended for both batch and in-line equipment. These systems have higher freeboard and a secondary set of low-temperature (-29°C [-20°F]) condenser coils to reduce vapor loss.

Vertrel® MCA has a broad range of cleaning capabilities. **Table 3** lists some typical soils readily removed from parts in a short vapor degreasing cycle.

**Table 3**  
Soils Cleaned with Vertrel® MCA

Cutting Oils	Stamping Oils
Gear Oils	Vacuum Oils
Heavy Greases	Waxes
Hydraulic Oils	Mineral Oils

### Plastic and Elastomer Compatibility

Vertrel® MCA is compatible with most polymeric materials commonly encountered in degreasing of precision parts. Acrylic, ABS, and polycarbonate parts, particularly if under stress, may show slight cracking or crazing damage and should be tested. EPDM, butyl rubber, Buna-S, and neoprene are recommended for elastomeric parts.



*The miracles of science™*

**Tables 4 and 5** summarize test results on short-term exposures of unstressed plastics and elastomers simulating a typical cleaning cycle. Long-term compatibility data simulating exposure of vapor degreaser construction materials is available from DuPont upon request.

Elastomer swelling and shrinking will, in most cases, revert to within a few percent of original size after air drying. Swell, shrinkage, and extractables are strongly affected by the compounding agents, plasticizers, and curing used in the manufacture of plastics and elastomers. Therefore, prior in-use testing is particularly important.

**Table 4**  
**Plastic Compatibility**  
**Immersion: 15 Minutes at Room Temperature**

Compatible	
Polyethylene	Acetal
Polyvinylchloride	Epoxy
Polyester, PET, PBT	Liquid Crystal Polymer
Polyimide, PI, PEI, PAI	Phenolic
Polyetherketone, PEK	PTFE, ETFE
Polyaryletherketone, PEEK	Chlorinated PVC
Polyarylsulfone, PAS	Ionomer
Polypropylene	ABS
Polyphenylene Sulfide, PPS	Polysulfone, PSO
Incompatible <sup>a</sup>	
Polystyrene	Acrylic
Polyphenylene Oxide, PPO	Cellulosic

<sup>a</sup> Material composition varies depending upon compounding agents, plasticizers, processing, etc. Specific materials should be tested for compatibility with solvent.

**Table 5**  
**Elastomer Compatibility**  
**Immersion: 15 Minutes at Room Temperature**

Compatible	
Buna N, NBR, Nitrile	Buna S, SBR, GRS
Butyl Rubber, IIR	Chlorosulfonated PE
EPM, EPDM, Nordel®	Polysulfide
Natural Rubber, Isoprene	Neoprene
Urethane	Viton® B
	Silicone
Incompatible <sup>a</sup>	
None Tested	

<sup>a</sup> Material composition varies depending upon compounding agents, plasticizers, processing, etc. Specific materials should be tested for compatibility with solvent.

## Metals and Other Compatibility

Vertrel® MCA was found compatible with aluminum, copper, and iron, with and without oil present, after exposure for 2 weeks at 120°C (248°F) in sealed tubes.

Contact with highly basic process materials, pH 10 or above, is not recommended.

## Exposure Limits

Data from acute toxicity studies has demonstrated that Vertrel® MCA has low toxicity. It is a slight skin and eye irritant and has low inhalation toxicity. **Table 6** shows the applicable exposure limits for the component materials of Vertrel® MCA.

AEL and TLV limits are time weighted average (TWA) concentrations for a normal 8- or 12-hr workday and a 40-hr workweek, to which nearly all workers may be repeatedly exposed, day after day, without adverse effect. Please refer to the Material Safety Data Sheet for additional details.

**Table 6**  
**Exposure Limits**

Component	Limit, ppm	Type
Vertrel® XF	AEL <sup>a</sup> 200 400	8- and 12-hr TWA Ceiling <sup>b</sup>
Trans-1,2-dichloroethylene	TLV <sup>c</sup> 200	8-hr TWA
Vertrel® MCA	AEL <sup>a, b</sup> 200	Calculated <sup>d</sup>

<sup>a</sup> AEL (Acceptable Exposure Limit) is an airborne inhalation exposure limit established by DuPont that specifies time-weighted average concentrations to which nearly all workers may be repeatedly exposed without adverse effects.

<sup>b</sup> A ceiling limit is the concentration that should not be exceeded during any part of the working day. The ceiling limit for individual components applies to the blend product as well.

<sup>c</sup> TLV (Threshold Limit Value) is an air-borne inhalation exposure limit established by the American Conference of Government and Industrial Hygienists (ACGIH) that specifies time-weighted average concentrations to which nearly all workers may be repeatedly exposed without adverse effects.

<sup>d</sup> Calculated in accordance with ACGIH formula for TLVs for mixtures.

## Safety/Flammability

Vertrel® MCA exhibits no closed cup or open cup flash point, and is not classified as a flammable liquid by NFPA or DOT. In addition, the product has no vapor flammability limits in air.

Flash point data and limits of flammability in air provide the user with additional information that should be used as elements of a fire risk assessment and to determine guidelines for the safe handling of volatile chemicals. Users should assure compliance with NFPA standards and local fire codes.

## Recovery

Due to the azeotropic nature of Vertrel® MCA, the product is easily recoverable by off-line or in-line distillation equipment such as a vapor degreaser or still. The presence of soil, however, may alter the characteristics of the material during the recovery operation. Recovery should be closely monitored to ensure operating levels are maintained. Users should test the spent Vertrel® MCA to ensure proper classification for waste disposal.

## Storage/Handling

Vertrel® MCA is thermally stable and does not oxidize or degrade during storage. Store in a clean, dry area. Protect from freezing temperatures. If solvent is stored below -10°C (14°F), mix prior to use. Do not allow stored product to exceed 52°C (125°F) to prevent leakage or potential rupture of container from pressure and expansion.

Consideration should be given to retrofit of existing, or purchase of new, vapor degreasing equipment to provide vapor containment technology that enables safe and economical use of Vertrel® MCA.

Drum pumps are recommended to dispense Vertrel® MCA from its container. Refer to the Material Safety Data Sheet for specific handling precautions and instructions.

## Environmental Legislation

Vertrel® specialty fluids have “zero” ozone depletion potential and low global warming potential (**Table 7**). They are used as alternatives to CFC-113, methylchloroform, hydrochlorofluorocarbons (HCFCs), and perfluorocarbons (PFCs) in many critical cleaning, drying, carrier fluid, and other high-value specialty uses where reliability is paramount.

Vertrel® MCA is accepted by the U.S. Environmental Protection Agency (EPA) under the Significant New Alternatives Policy (SNAP) program, as a substitute for ozone-depleting substances.

The components of Vertrel® MCA are listed in most country chemical inventories, such as TSCA in the U.S., ELINICS in Europe, Chemical Substances Control Law (MITI/MHW) in Japan, DSL (notified) in Canada, NICNAS in Australia, and TCCL in Korea.

Vertrel® MCA is not a hazardous air pollutant (HAP), and therefore, not subject to NESHAP regulation. Vertrel® MCA is not included in the SARA Title III Section 313 list of toxic chemicals, and is not subject to SARA Title III (EPCRA) reporting requirements.

**Table 7**  
**Environmental Properties**

Property	Vertrel® MCA
Ozone-Depletion Potential (ODP)	0
Global Warming Potential (GWP/100 yr ITH)	806
Volatile Organic Compounds (VOC, g/L)	536

## Packaging and Availability

Vertrel® MCA is available commercially in 55-gal (208-L) drums with a net weight of 550 lb (249 kg) and in 5-gal (19-L) pails with a net weight of 50 lb (23 kg). One-gallon and smaller samples in glass containers are available on request. Customers are encouraged to secure samples now for compatibility and performance testing.

## Specifications

Composition and specifications are shown in **Table 8**. All components are listed in the TSCA Inventory.

**Table 8**  
**Vertrel® MCA Specifications**

Vertrel® XF, wt%	62.0 ± 1.0
Trans-1,2-dichloroethylene, wt%	38.0 ± 1.0
Total Purity, wt%	99.8 min.
Nonvolatile Residue, ppm wt	10 max.*
Moisture, ppm wt	100 max.
Acidity (as HCl), ppm wt	1.0 max.
Chloride, ppm wt	1.0 max.
Particle Count, mg/L	2.0 max.
Appearance	Clear, colorless

\*50 ppm max. in 5-gal pails.

---

## North America, Canada, Mexico

Micro Care Marketing Services  
595 John Downey Drive  
New Britain, CT 06051  
Tel: (888) 595-4525  
Fax: (860) 827-8105



## Europe, Africa, Middle East

DuPont de Nemours  
International S.A.  
2 Chemin du Pavillon  
P.O. Box 50  
CH-1218 Le Grand-Saconnex  
Geneva, Switzerland  
41-22-717-5111

## South America

DuPont do Brasil S.A.  
Alameda Itapecuru, 506  
Alphaville 06454-080 Barueri  
Sao Paulo, Brazil  
55-11-7266-8263

## Pacific

DuPont Australia  
P.O. Box 930  
North Sydney, NSW  
Australia 2060  
61-2-923-6165

## Japan

DuPont-Mitsui  
Fluorochemicals  
Co., Ltd.  
Chiyoda Honsha Bldg.  
5-18 Sarugaku-cho 1-Chome  
Chiyoda-Ku, Tokyo 101,  
Japan  
(03) 5281-5805

## Asia

DuPont Taiwan  
P.O. Box 81-777  
Taipei, Taiwan  
886-2-514-4400

DuPont Asia Pacific, Ltd.  
P.O. Box TST 98851  
Tsim Sha Tsui  
Kowloon, Hong Kong  
852-734-5345

DuPont Thailand  
G.P.O. Box 2398  
Bangkok 10500, Thailand  
66-2-236-0026

DuPont Far East, Inc.  
8/F Solid Bank Bldg.  
777 Paseo de Roxas  
Makati 1226 Philippines  
63-2-818-9911

DuPont Far East Inc.  
P.O. Box 7882  
40702 Shah Alam, Malaysia  
60-3-519-3006

DuPont Korea Ltd.  
C.P.O. Box 5972  
Seoul, Korea  
82-2-721-5114

DuPont Singapore Pte. Ltd.  
1 Maritime Square #07 01  
World Trade Centre  
Singapore 0409  
65-273-2244

---

The information set forth herein is based on data believed to be reliable, but the DuPont Company makes no warranties express or implied as to its accuracy and assumes no liability arising out of its use by others. This publication is not to be taken as a license to operate under, or recommendation to infringe, any patent.



*The miracles of science™*